




VegaForce Company
<http://www.gb-tech.com.tw>

M40A5 ADDITIONAL INSTRUCTIONS


■ How to use M40A5 gas magazine



Push magazine catch and take down magazine



Charging GAS (about 4~6 sec.)



Using the BB loader to Loading BBs (Max 14 round)

■ Gas bolt take down




Pull up charging handle



Push bolt release bottom and hold



Pull out bolt assembly



■ Hop-Up Adjusting

Use 1.5mm hex wrench to adjust Hop-Up

- Turn adjustment screw clockwise to raise BB's trajectory.
- Turn adjustment screw counter clockwise to reduce BB's trajectory.



■ Loading indicator

- Loading indicator will rise out when rifle is ready to fire.
- If not in shooting, Please take magazine off and pull trigger to release hammer.

01 UPPER RECEIVER

01-1	PSCW030804
01-2	PSCW031204
01-3	VGS1HGD010
01-4	PSCW030503
01-5	VGS2BLT010
01-6	PB0T042002
01-7	VGS2SPG001
01-8	VGS2BLT020
01-9	PB0T031802
01-10	VGS2BLT030

03 BARREL / FOREARM

03-1	VGS1FHR010
03-2	PRIG0000005
03-3	VGS1FHR020
03-4	VGS1BRL010
03-5	VGS2BRL040
03-6	PRIG000074
03-7	VGS2BRL050
03-8	PRIG000015

04 STOCK

04-1	VGS1STK010
04-2	PWAS100005
04-3	VOS1STK080
04-4	VAS0SST130
04-5	VAS0SST120
04-6	PSCW051504
04-7	VAS0SST110
04-8	PSCW0520A4
04-9	VOS1STK090
04-10	VOS1STK051
04-11	VOS1STK060
04-12	VOS1STK0B0
04-13	PRIG0000051
04-14	VOS1STK020
04-15	PSCW041022
04-16	VOS1STK030
04-17	VOS1STK040
04-18	VOS1STK0D0
04-19	PSCW056004
04-20	VOS1STK070
04-21	PB0T031802
04-22	VGS1LRV010
04-23	PSCW053004
04-24	PSCW053504
04-25	VGS1MAG030
04-26	VGS2SPG005

06 MAGAZINE

06-1	VGS1MAG000
------	------------

07 HOP SYSTEM

07-1	VGS2BRL030
07-2	VGS2BRL020
07-3	VGS2BRL010
07-4	V003TUB555
07-5	VGS2HOP010
07-6	VGS2SPG005
07-7	VGS2HOP050
07-8	VG00HOP010
07-9	VGS2HOP030
07-10	VGS2HOP020
07-11	VG00HOP020
07-12	VGS2HOP070
07-13	VGS2HOP040
07-14	VGS2HOP060
07-15	PB0T020702
07-16	PB0T020501

08 TRIGGER SYSTEM

08-1	VGS2THG090
08-2	VGS2MSY020
08-3	VGS2MSY010
08-4	PBAL040001
08-5	VGS2THG020
08-6	VGS2PLK020
08-7	VGS2THG080
08-8	VGS2SPG008
08-9	PBUKEETW20
08-10	VGS2THG060
08-11	VGS2SPG006
08-12	VGS2THG040
08-13	VGS2THG010
08-14	VGS2PLK010
08-15	VGS2THG050
08-16	VGS2THG030
08-17	VGS2SPG007
08-18	VGS2BLT0C0
08-19	VGS2MSY030
08-20	PSCW020822
08-21	VGS2THG070
08-22	PSCW020622

09 BOLT CARRIER

09-1	VGS2BLT050
09-2	PSCW030403
09-3	VGS2BLT040
09-4	VGS2BLT070
09-5	VGS2BLT060
09-6	VGS2FPN020
09-7	VGS2SPG002
09-8	VGS2BLT090
09-9	VGS2BLT0A0
09-10	VGS2BLT080
09-11	VGS2BLT0B0
09-12	VGS2SPG004
09-13	VGS2FPN010
09-14	PB0T010002
09-15	VGS2SPG003
09-16	VGS2FPN030

